

Assembly Instructions

PARTS INCLUDED

- **1 Main Shelf Body**
 - Bottom wire platform
 - Back panel with mounting hooks
- **2 Fold-Out Side Panels** (attached)
- **2 Retaining Clips** (attached to side panels)

No tools required.

ASSEMBLY INSTRUCTIONS

1. Position the Shelf

- Place the shelf on a flat surface.
 - Ensure the **bottom platform is facing down**.
 - The **mounting hooks should point upward at the back**.
-

2. Raise the Left Side Panel

- Locate the folded left side panel.
 - Swing it **upward and outward** until it forms a 90° angle with the bottom.
 - Ensure it aligns with the front and back wire frame.
-

3. Lock the Left Clip

- Locate the attached retaining clip.
- Rotate or press the clip into position so it wraps around the shelf's bottom/front wire.
- Push firmly until secure.
- Confirm the side panel does not fold inward.

4. Raise the Right Side Panel

- Swing the right side panel upward to a 90° angle.
 - Align it evenly with the frame.
-

5. Lock the Right Clip

- Secure the retaining clip in place.
 - Ensure both sides are stable and symmetrical.
-

FINAL CHECK

- ✓ Both side panels upright and secure
 - ✓ Clips fully engaged
 - ✓ Shelf sits level
 - ✓ Panels do not fold inward when lightly pressed
-

WALL / PANEL MOUNTING

1. Lift the assembled shelf.
 2. Align rear mounting hooks with wall panel or grid.
 3. Insert hooks into slots.
 4. Press downward to lock in place.
 5. Confirm shelf is level before loading items.
-

TO FOLD FOR STORAGE

1. Release both retaining clips.
 2. Fold side panels inward.
 3. Store flat.
-

ALL-PURPOSE VIDEO SHELF

page 3

IMPORTANT:

Do not exceed recommended weight capacity for your wall system. Ensure shelf is fully secured before loading.